



# 9730 Series Pulse Generator Operating Manual



Version 0.3

Quantum Composers, INC  
212 Discovery Drive  
Bozeman, MT 59718  
Phone: (406)582-0227  
Fax: (406)582-0237

[www.quantumcomposers.com](http://www.quantumcomposers.com)

# 1 Table of Contents

|  |             |
|--|-------------|
| <b>1 TABLE OF CONTENTS</b> .....                       | <b>1-2</b>  |
| <b>2 INTRODUCTION</b> .....                            | <b>2-5</b>  |
| TECHNICAL SUPPORT .....                                | 2-5         |
| WARRANTY .....   | 2-5         |
| PACKAGE CONTENTS .....                                 | 2-5         |
| <b>3 SAFETY ISSUES</b> .....                           | <b>3-6</b>  |
| <b>4 PRODUCT OVERVIEW</b> .....                        | <b>4-7</b>  |
| <i>Key Features</i> .....                              | 4-7         |
| <i>Advanced Features/Options</i> .....                 | 4-7         |
| <b>5 PULSE GENERATOR CONCEPTS AND OPERATION</b> .....  | <b>5-8</b>  |
| <i>System Timer Functions</i> .....                    | 5-8         |
| <i>Channel Timer Functions</i> .....                   | 5-8         |
| <i>Dependent &amp; Independent Timing Events</i> ..... | 5-8         |
| <i>Navigating the 9730 Front Panel</i> .....           | 5-9         |
| <b>6 FRONT PANEL OVERVIEW</b> .....                    | <b>6-11</b> |
| 9730 DISPLAY .....                                     | 6-11        |
| <i>Display Layout and Indicators</i> .....             | 6-11        |
| DESCRIPTION OF FRONT PANEL AREA .....                  | 6-11        |
| <i>Keypads and Keys</i> .....                          | 6-11        |
| <i>Second Level Menus (Function Key)</i> .....         | 6-12        |
| <i>Channel Outputs (BNC Connectors)</i> .....          | 6-12        |
| <i>Channel Status LED Indicators</i> .....             | 6-12        |
| <i>Arm Switch (Keyed)</i> .....                        | 6-13        |
| <i>System Status LED Indicators</i> .....              | 6-13        |
| <i>Front Sync Output</i> .....                         | 6-13        |
| <i>Front Trigger Input</i> .....                       | 6-13        |
| <b>7 REAR PANEL OVERVIEW</b> .....                     | <b>7-14</b> |
| DESCRIPTION OF REAR PANEL AREA .....                   | 7-14        |
| <i>Channel Connections (Banana Jacks)</i> .....        | 7-14        |
| <i>Rear Sync Output</i> .....                          | 7-14        |
| <i>Rear Trigger Input</i> .....                        | 7-14        |
| <i>Interlock Short</i> .....                           | 7-14        |
| <i>Communication Ports</i> .....                       | 7-14        |
| <i>Voltage Input (AC)</i> .....                        | 7-14        |
| <i>Cooling Fans</i> .....                              | 7-15        |
| <b>8 MENU STRUCTURE</b> .....                          | <b>8-16</b> |
| <i>MODE Menu (FUNC + 1)</i> .....                      | 8-16        |
| <i>RATE Menu (FUNC + 4)</i> .....                      | 8-16        |
| <i>Channel Menu (A, B, C, or D)</i> .....              | 8-17        |
| <i>Channel Test Menu (FUNC + A, B, C, or D)</i> .....  | 8-18        |
| <i>TRIG Menu (TRIG)</i> .....                          | 8-19        |
| <i>Counter Menu (FUNC + 8)</i> .....                   | 8-19        |
| <i>SYSTEM Menu (FUNC + 3)</i> .....                    | 8-20        |
| <i>STORE Menu (FUNC + 6)</i> .....                     | 8-21        |
| <i>RECALL Menu (FUNC + 9)</i> .....                    | 8-21        |

|  |              |
|--|--------------|
| <b>9 OPERATING INSTRUCTIONS.....</b>                         | <b>9-22</b>  |
| QUICK START – INTERNAL SINGLE SHOT GENERATOR OPERATION ..... | 9-22         |
| <i>Pulse Width, Delay</i> .....                              | 9-22         |
| <i>Amplitude</i> .....                                       | 9-22         |
| <i>Enable</i> .....  | 9-22         |
| <i>Interlock</i> .....                                       | 9-22         |
| <i>Wait for Charge</i> .....                                 | 9-22         |
| <i>ARM Key Switch</i> .....                                  | 9-22         |
| <i>Start</i> .....   | 9-22         |
| QUICK START – SINGLE SHOT EXTERNAL TRIGGER OPERATION .....   | 9-23         |
| <i>Trig</i> .....  | 9-23         |
| <i>Level</i> .....   | 9-23         |
| <i>Edge</i> .....  | 9-23         |
| <i>Filter</i> .....  | 9-23         |
| <i>Source</i> .....  | 9-23         |
| <i>Pulse Width, Delay</i> .....                              | 9-23         |
| <i>Amplitude</i> .....                                       | 9-23         |
| <i>Enable</i> .....  | 9-23         |
| <i>Interlock</i> .....                                       | 9-23         |
| <i>Wait for Charge</i> .....                                 | 9-24         |
| <i>ARM Key Switch</i> .....                                  | 9-24         |
| <i>Start</i> .....   | 9-24         |
| STANDARD OPERATION MODES .....                               | 9-24         |
| <i>System Pulse Generation Overview</i> .....                | 9-24         |
| <i>Single Shot Mode (Trigger Disabled)</i> .....             | 9-24         |
| <i>Burst Mode (Trigger Disabled)</i> .....                   | 9-24         |
| <i>External Input Overview</i> .....                         | 9-25         |
| <i>Single Shot Mode (Trigger Enabled)</i> .....              | 9-26         |
| <i>Burst Mode (Trigger Enabled)</i> .....                    | 9-26         |
| SPECIAL TESTING MODES.....                                   | 9-27         |
| <i>Pre Pulse Resistance Testing</i> .....                    | 9-27         |
| <i>Post Pulse Resistance Testing</i> .....                   | 9-27         |
| <i>Testing Mode Error Conditions</i> .....                   | 9-28         |
| <b>10 PROGRAMMING THE 9730 .....</b>                         | <b>10-29</b> |
| PERSONAL COMPUTER TO PULSE GENERATOR COMMUNICATION .....     | 10-29        |
| <i>RS232 Interface Overview</i> .....                        | 10-29        |
| <i>USB Interface Overview</i> .....                          | 10-30        |
| <i>Ethernet Interface Overview</i> .....                     | 10-31        |
| PROGRAMMING COMMAND TYPES AND FORMAT .....                   | 10-31        |
| <i>Line Termination</i> .....                                | 10-31        |
| <i>IEEE 488.2 Common Command Format</i> .....                | 10-32        |
| <i>SCPI Command Keywords</i> .....                           | 10-32        |
| <i>SCPI Keyword Separator</i> .....                          | 10-32        |
| <i>SCPI Optional Keywords</i> .....                          | 10-33        |
| <i>SCPI Parameter Types</i> .....                            | 10-33        |
| <i>Legacy Command Support</i> .....                          | 10-33        |
| <i>Error Codes</i> .....                                     | 10-33        |
| PROGRAMMING EXAMPLES .....                                   | 10-34        |
| <i>Example 1:</i> .....                                      | 10-34        |
| <i>Example 2:</i> .....                                      | 10-34        |
| 9730 SCPI COMMAND SUMMARY .....                              | 10-35        |
| <i>Instrument Commands</i> .....                             | 10-35        |
| <i>System Pulse Commands</i> .....                           | 10-36        |
| <i>Channel Commands</i> .....                                | 10-37        |

|  |            |
|--|------------|
| <i>Display Commands</i> .....            | 10-37      |
| <i>System Commands</i> .....             | 10-38      |
| IEEE 488.2 COMMON COMMANDS .....         | 10-39      |
| <b>APPENDIX A - SPECIFICATIONS</b> ..... | <b>A-1</b> |
| <b>APPENDIX B - SAFETY SYMBOLS</b> ..... | <b>B-1</b> |
| SAFETY MARKING SYMBOLS .....             | B-1        |

## 2 Introduction

This manual is designed to familiarize you with the Quantum Composers 9730 series pulse generator and is arranged so that you can easily find the information for which you are looking. Generally, each topic has its own section and no section assumes that you have read anything else in the manual.

### ***Technical Support***

For questions or comments about operating the 9730 our technical staff can be reached via one of the following methods:

- Phone: (406) 582-0227
- Fax: (406) 582-0237
- Online: [www.quantumcomposers.com](http://www.quantumcomposers.com)

### ***Warranty***

In addition to a 30 day money back guarantee, the 9730 has a one-year limited warranty from the date of delivery. This warranty covers defects in materials and workmanship. Quantum Composers will replace any defective unit. Contact us for information on obtaining warranty service.

### ***Package Contents***

The box you receive should contain the following:

- 9730 Pulse Generator
  - ❖ AC Power Cord
  - ❖ Accessories
    - Arm Switch Keys (qty 2)
    - 50 Ohm Interlock Shorting Jumper (BNC)
- Disc that includes
  - Operating Manual
  - Software Drivers
  - Communication Software

Contact Quantum Composers at (406)582-0227 if any parts are missing.

## 3 Safety Issues

Normal use of equipment exposes users to a certain amount of danger from electrical shock because testing must be performed where exposed voltage is present. An electrical shock causing 10 milliamps of current to pass through the heart will stop most human heartbeats. Voltages as low as 35 V (DC or RMS AC) should also be considered dangerous and hazardous since they can produce a lethal current under certain conditions. Higher voltages pose an even greater threat because such voltage can more easily produce a lethal current. Your normal work habits should include all accepted practices that will prevent contact with exposed high voltage, and those that will steer current away from your heart in case of accidental contact with a high voltage. You will significantly reduce the risk factor if you know and observe the following safety precautions:

- If possible, familiarize yourself with the equipment being tested and the location of its high-voltage points. However, remember that high voltage may appear at unexpected points in defective equipment.
- Do not expose high voltage components needlessly. Remove housings and covers only when necessary. Turn off equipment while making test connections in high-voltage circuits. Discharge high-voltage capacitors after removing power.
- Use an insulated floor material or a large, insulated floor mat to stand on, and an insulated work surface on which to place equipment. Make certain such surfaces are not damp or wet.
- Use the time-proven “one hand in the pocket” technique while handling an instrument probe. Be particularly careful to avoid contacting a nearby metal object that could provide a good ground return path.
- When testing AC powered equipment, remember that AC line voltage is usually present on some power input circuits, such as the on-off switch, fuses, power transformer etc., and any time the equipment is connected to an AC outlet, even if the equipment is turned off.
- Never work alone. Someone should always be nearby to render aid if necessary. Training in CPR first aid is highly recommended.

## 4 Product Overview

The 9730 series combines industry leading QC digital delay methodologies along with high capacity charge banks to generate precisely timed adjustable amplitude current pulses. This ability to generate highly precise current pulses makes this unit ideal for applications that require a high level of accuracy and repeatability.

### Key Features

- Up to 4 individual outputs with fully individual programming and control.
- Up to 6A output per channel (Standard Instrument).
- Complete channel and system setup stored in memory. Provides 12 memory storage slots.
- Remote programmability – RS232, USB and Ethernet.
- Front and rear external trigger inputs.

### Advanced Features/Options

- Resistance measurement (4 wire) for each channel with pre and post pulse testing features.
- Current and voltage monitor outputs.
- Front and rear sync outputs.
- Safety features including remote interlock and removable keyed enable switch.

# 5 Pulse Generator Concepts and Operation

## System Timer Functions

- **Burst Mode**  
The System Timer functions as a non-retriggerable, multi-vibrator  $T_0$  pulse generator in 'Burst' [mode](#). This means that once started the timer will produce pulses continuously at the specified [rate](#) until the highest channel [burst count](#) is reached. Before pulses can be generated, the timer must be armed and then receive a System Start pulse. Arming the counter is done by pressing the **RUN/STOP** key. With external trigger disabled, the **RUN/STOP** key or a software [trigger command](#) may be used to generate the System Start pulse for the counter. With external trigger enabled, the **RUN/STOP** key or software [trigger command](#) arms the unit and the subsequent external trigger pulses replace the  $T_0$  pulses.
- **Single Shot Mode**  
In 'Single Shot' [mode](#), the System Timer is bypassed and the  $T_0$  pulse is generated directly from the System Start pulse.

The  $T_0$  pulses are distributed to the Channel Start input of all of the Channel Timers.

## Channel Timer Functions

The Channel Timer functions as a non-retriggerable, delayed, one shot pulse generator. This means that the timer will only generate one delayed pulse for every Channel Start pulse received. Once the channel timer has started counting, additional start pulses will be ignored until the pulse has been completed (non-retriggerable). The Channel Start pulse for each channel is provided by the internal  $T_0$  pulse.

Whether or not a pulse is generated for each  $T_0$  pulse is determined by the channel [enable](#) setting. Pulses are defined by a time [delay](#), from their sync or start pulse to the active edge, a time [width](#) over which the pulse is active, and an [amplitude](#) during the active portion of the pulse.

## Dependent & Independent Timing Events

The 9730 allows the user to control the relationship between the Channel Timers by setting the [sync](#) source for each timer. Independent events are all timed relative to the internal  $T_0$  start pulse. Dependent events may be linked together by setting the sync source to the controlling event. This allows the instrument to match the timed events and adjustments can be made in one event without detuning the timing between it and a dependent event.

## Navigating the 9730 Front Panel

- **Selecting Menus**

Parameters are grouped in menus, selectable using the function keys. To select the output channel parameters, press the letter key corresponding to the desired channel. To select other menus, including the channel test menus, press the **FUNC** key and then the key corresponding to the desired function.

Menus may include a number of different pages, with each page containing up to four adjustable parameters or state variables. The status block in the upper-left corner of the display shows a vertical arrow if the current menu contains additional pages. To select the next page, press the channel button again or select the same menu pressing the **FUNC** key and the channel/menu key again.

- **Selecting Menu Items**

Within a menu, the blinking cursor indicates the current menu item for editing. The **NEXT** key will select a different adjustable menu item.

- **Numeric Input Mode**

When the current item is numeric, the system enters the Numeric Input Mode. In this mode data may be edited in one of two ways:

- Arrow Keypad - The Left and Right arrow keys are used to select a digit to edit. The selected digit blinks to identify itself as the active digit. The Up and Down arrow keys are then used to increment or decrement this digit.
- Numeric Keypad - Enter the number, including decimal point using the numeric keypad. Complete the number using the **ENTER** key. Errors may be corrected using the backspace key or to start over press the clear key (CLR). Pressing the **CLR** key a second time will exit the numeric keypad mode and restore the original number.

- **Entering Non-Numeric Parameters**

When the current item is non-numeric, the Up and Down arrow keys are used to select among different options for the parameter.

- **Alphanumeric Input Mode**

When the current item is alphanumeric, the system enters the Alphanumeric Input Mode. In this mode, data is entered using the alphanumeric keypad. Pressing a key will display the first letter shown on the keypad. Repeated key presses will toggle through all the letters, both upper and lower case, shown on the key cap. To enter two letters which appear on the same key cap, select the first character, then use the right arrow to shift to the next position and enter the next letter. The Left and Right arrow keys may be used to position the cursor to edit any character.

When data entry is complete, the ENTER key must be pressed. The keys contain the following characters:

- 1 => 1 2 3 4 5 6 7 8 9 0
- 2 => A B C a b c 2
- 3 => D E F d e f 3
- 4 => G H I g h i 4
- 5 => J K L j k l 5
- 6 => M N O m n o 6
- 7 => P Q R S p q r s 7
- 8 => T U V t u v 8
- 9 => W X Y Z w x y z 9
- 0 => 0 1 2 3 4 5 6 7 8 9
- . => . , # \$ % & ?
- - => - + \* / space

- **Enabling System Output**

The RUN/STOP key is used to arm the system. With external trigger disabled, the key will arm and start pulse output. With external trigger enabled, the key will arm the pulse generator. Pulse output then starts after the first valid trigger input. With external trigger enabled, pressing the RUN/STOP key a second time disables the pulse generator.

# 6 Front Panel Overview

## *9730 Display*

### **Display Layout and Indicators**

A graphical display module displays parameters and status information. The status information is located in the upper-left corner of the display, between the two brackets. There are three enunciators:

- ❖ Vertical Arrow            Indicates there are additional pages to the current Menu.
- ❖ Blinking Circle         Indicates the unit is actively generating pulses, or armed and waiting for an external trigger.
- ❖ Musical Note            Indicates the function key has been pressed

The upper-right side of the display contains the title of the currently displayed menu. The rest of the display is used for system parameters. The display brightness may be adjusted, allowing the instrument to be used under various lighting conditions.

### ***Description of Front Panel Area***

#### **Keypads and Keys**

Four keypads provide fast access to various menus and easy editing of system parameters.

- Channel Keys            Provides one touch access to the desired [channel menu](#) for setting up the channel parameters. The channel menu keys are indicated with a capital letter corresponding to the channel (e.g. press the **A** key to display the menu corresponding to channel A). The **FUNC** key (solid yellow key at the bottom center of the numeric keypad) allows the channel keys to select the [channel test menus](#).
- Trigger Key             Provides one touch access to the [trigger menu](#) for setting up trigger parameters. The trigger menu key is indicated with the letters **TRIG**.
- Arrow Keypad            The up and down arrows (referred to as **UP** and **DOWN** keys for the rest of this document) are used to increment/decrement the current parameter (indicated by the blinking cursor). The position of the cursor controls the step size for each increment. The right

and left arrows (referred to as **LEFT** and **RIGHT** keys for the rest of this document) move the cursor to different positions within the current parameter. The **NEXT** key selects the next parameter in the currently displayed menu.

- **Numeric Keypad** Allows numbers and alphanumeric values to be entered. When entering alphanumeric values, pressing a key will display the first letter shown on the key. Repeated key presses will toggle through all the letters, both upper and lower case, shown on the keycap. To enter two letters which appear on the same keycap, select the first character, then use the right arrow to shift to the next position and enter the next letter. When data entry is complete the **ENTER** key must be pressed. The **FUNC** key allows a key to select the secondary function/menu in yellow directly above the key.

### **Second Level Menus (Function Key)**

The second level menus (indicated in yellow above certain keys) are accessed through the use of the yellow **FUNC** key. Pressing the **FUNC** key once and then pressing the desired menu key will display the specified second level menu. Pressing the **FUNC** key twice in succession will put the unit into Function Lock mode, where the second level menus can be accessed without repeatedly pressing the **FUNC** key. Pressing the **FUNC** key a third time will exit Function Lock mode.

### **Channel Outputs (BNC Connectors)**

Each channel has two outputs on the front panel:

1. **Voltage Monitor** This is an analog representation in volts of the voltage output to the load. The transfer function of this follower is 1 V/V, as listed directly below the monitor BNC connector.
2. **Current Monitor** This is an analog representation in volts of the current output to the load. The transfer function of this follower is 1 A/V, as listed directly above the monitor BNC connector.

### **Channel Status LED Indicators**

Each channel has four panel LED indicators and one button led indicator to reflect the current status of the channel:

- **ARMED** Green LED indicating the channel is armed and ready.

- CHARGE READY Amber LED indicating the channel capacitor bank is charged and ready.
- RESISTOR FAULT Red LED indicating the pre test error status of the current channel.
- GROUND FAULT Red LED indicating the pre test error status of the current channel.
- Channel Button Green LED back illuminating button text when the channel is enabled.

### **Arm Switch (Keyed)**

The upper right hand corner of the front panel contains a safety Arm Switch which may be turned to the 'STANDBY' position while changing parameters to ensure no pulses are generated. This switch must be in the 'ARM' position in order to allow generation of pulses.

NOTE: The Arm switch keys are included with the shipped [accessories](#).

### **System Status LED Indicators**

The system state has two front panel LED indicators to reflect the current system state:

- Power Green LED back illuminating button text when system is powered on.
- ARM Red LED indicating the system arm keyswitch is in the "Arm" position.
- Trigger Green LED back illuminating button text when the global system trigger is enabled.
- Run Green LED back illuminating button text while system is pulsing or ready to trigger.

### **Front Sync Output**

The front panel sync output is user selectable to output the TTL representation of the system pulse or any of the individual channels. This output is may also be disabled.

### **Front Trigger Input**

The front panel trigger input is user selectable as the source for the global system trigger.

# 7 Rear Panel Overview

## *Description of Rear Panel Area*

### **Channel Connections (Banana Jacks)**

Each channel has two sets of banana jacks for connecting to the device under test:

- **OUTPUT** Red and Black current jacks (labeled 'A' between them) connect to the positive and negative drive terminals (respectively) of the device under test.
- **MEASURE** Red and Black voltage sense jacks (labeled 'V' between them) connect to the positive and negative measurement terminals (respectively) of the device under test. This connection is optional when pre and/or post resistance tests are not enabled.

### **Rear Sync Output**

The rear panel sync output is user selectable to output the TTL representation of the system pulse or any of the individual channels. This output is may also be disabled.

### **Rear Trigger Input**

The rear panel trigger input is user selectable as the source for the global system trigger.

### **Interlock Short**

This is a protection jumper required for system or channels to enable or arm. It is labeled 'INTLK' on the rear panel overlay. A bypass shorting jumper is included with the instrument when shipped.

### **Communication Ports**

This instrument ships with RS232 and USB communications installed. An option to include Ethernet may be specified at the time the order is placed. The rear panel overlay labels for the communications connections are 'RS232', 'USB', and 'ETHERNET' respectively.

### **Voltage Input (AC)**

A switched and fused AC input connection is located on the rear panel along with markings indicating the required voltage and maximum current draw.

## **Cooling Fans**

The rear panel also contains one or two cooling fan outputs depending on whether the instrument has two or four channels respectively. Air is circulated in through the side panel vents and out through the rear panel fan openings.  
**WARNING: DO NOT BLOCK COOLING FAN INPUTS OR OUTPUT(S).**

# 8 Menu Structure

## **MODE Menu (FUNC + 1)**

- Page0
  - Line0 – empty
  - Line1 – Mode: Single Shot, Burst
  - Line2 – empty
  - Line3 – empty

### **Setting System Mode Parameters**

Mode: Selects the  $T_0$  mode: Single Shot or Burst mode.

## **RATE Menu (FUNC + 4)**

- Page0
  - Line0 – empty
  - Line1 – empty
  - Line2 – Per: <period>
  - Line3 – decimal place indicator

### **Setting System Rate Parameters**

Per: Sets the  $T_0$  period which determines the burst mode output frequency of the unit.

## **Channel Menu (A, B, C, or D)**

- Page0
  - Line0 – Channel: Enabled, Disabled
  - Line1 – Wid: <width>
  - Line2 – Dly: <delay>
  - Line3 – decimal place indicator
  
- Page1
  - Line0 – ‘Enable’ Enabled, Disabled
  - Line1 – empty
  - Line2 – Brst: <burst>
  - Line3 – Ampl: <amplitude>

### **Setting Channel Output Parameters**

|          |   |
|----------|---|
| ‘Enable’ | Enables or disables the channel for pulsing.  |
| Wid:     | Sets the channel pulsewidth.  |
| Dly:     | Sets the channel delay until active edge.   |
| Sync:    | Sets the channel synchronization source for dependent timing events   |
| Brst:    | Sets the burst count for the channel. When system is in ‘Single Shot’ mode, this parameter will display ‘(Disabled)’ and not be adjustable. |
| Ampl:    | Sets the amplitude of the output current pulse.   |

## **Channel Test Menu (FUNC + A, B, C, or D)**

- Page0
  - Line0 – PreTest: Disabled
  - Line1 – empty
  - Line2 – empty
  - Line3 – empty
- Page0 – Alt
  - Line0 – PreTest: Enabled
  - Line1 – Meas: “measured resistance”
  - Line2 – ResMax: <pretest maximum resistance>
  - Line3 – ResMin: <pretest minimum resistance>

### **Setting Channel Pre-Test Parameters**

PreTest: Enables or disables pre resistance test and requirements for the channel.

Meas: Displays the measured resistance from the last run pre-test.

ResMax: Sets the maximum resistance allowable for pulse generation.

ResMin: Sets the minimum resistance allowable for pulse generation.

- Page1
  - Line0 – PostTest: Disabled
  - Line1 – empty
  - Line2 – empty
  - Line3 – empty
- Page1 - Alt
  - Line0 – PostTest: Enabled
  - Line1 – Meas: “measured resistance”
  - Line2 – ResMin: <posttest minimum resistance>
  - Line3 – empty

### **Setting Channel Post-Test Parameters**

PreTest: Enables or disables post resistance test and requirements for the channel.

Meas: Displays the measured resistance from the last run post-test.

ResMin: Sets the minimum resistance allowable to consider a post-test as passed.

## **TRIG Menu (TRIG)**

- Page0
  - Line0 – empty
  - Line1 – Mode: Disabled
  - Line2 – empty
  - Line3 – empty
- Page0 – Alt
  - Line0 – empty
  - Line1 – Mode: Enabled
  - Line2 – Level: <trigger threshold level>
  - Line3 – Edge: <trigger edge>
- Page1
  - Line0 – empty
  - Line1 – Filter: Disabled
  - Line2 – empty
  - Line3 – empty
- Page1 - Alt
  - Line0 – empty
  - Line1 – Filter: Enabled
  - Line2 – MinWid: <minimum trigger pulse width>
  - Line3 – Source: Front Input, Rear Input

### **Setting Channel Post-Test Parameters**

|         |  |
|---------|--|
| Mode:   | Enables or disables external trigger operation.            |
| Level:  | Sets the trigger threshold level.                          |
| Edge:   | Sets the triggering edge to rising or falling.             |
| Filter: | Enables or disables minimum trigger pulse width filtering. |
| MinWid: | Sets the minimum allowable trigger pulse width.            |
| Source: | Sets the trigger input source to front panel or rear panel |

## **Counter Menu (FUNC + 8)**

- Page0
  - Line0 – empty
  - Line1 – Counter: Disabled, Enabled
  - Line2 – Counts: “system pulse count since reset”
  - Line3 – empty

### **Setting Counter Parameters**

|          |  |
|----------|--|
| Counter: | Enables or disables the $T_0$ pulse counter. |
| Counts:  | Returns the current value of the counter.    |

## **SYSTEM Menu (FUNC + 3)**

- Page0
  - Line0 – empty
  - Line1 – Front Sync: Disabled, T0, ChA, ChB, (ChC, ChD)
  - Line2 – Rear Sync: Disabled, T0, ChA, ChB, (ChC, ChD)
  - Line3 – empty
  
- Page1
  - Line0 – empty
  - Line1 – empty
  - Line2 – Baud Rate: <RS232 baud rate>
  - Line3 – Echo: <RS232 echo>
  
- Page2
  - Line0 – empty
  - Line1 – Key Rate: <key rate>
  - Line2 – Key Vol: <key volume>
  - Line3 – empty
  
- Page3
  - Line0 – empty
  - Line1 – Mark: <decimal point indicator>
  - Line2 – LCD: <LCD brightness>
  - Line3 – empty

### **Setting System Parameters**

- Front Sync: Sets the source of the front panel sync output signal set to the front panel. Choices are Disabled, T<sub>0</sub>, ChA, and ChB for two channel instruments, with ChC and ChD added for four channel instruments.
- Rear Sync: Sets the source of the rear panel sync output signal set to the front panel. Choices are Disabled, T<sub>0</sub>, ChA, and ChB for two channel instruments, with ChC and ChD added for four channel instruments.
- Baud Rate: Sets the baud rate for the RS232 communications port.
- Echo: Enables or disables command echoing for the RS232 communications port.
- Key Rate: Sets the key repeat rate (useful for modifying the rate at which parameters adjust)
- Key Vol: Sets the perceived key beep volume by adjusting the beep time.
- Mark: Sets which character, either a ‘,’ or a ‘.’, to use as a decimal point indicator.

## **STORE Menu (FUNC + 6)**

- Page0
  - Line0 – empty
  - Line1 – Store#: <configuration# 1-12>
  - Line2 – Name: <configuration name>
  - Line3 – empty

### **Setting Store Parameters**

Store#: Sets which user bin to store the current instrument setup.

Name: Allows the user to rename the user bin.

## **RECALL Menu (FUNC + 9)**

- Page0
  - Line0 – empty
  - Line1 – Recall#: <configuration# 0-12>
  - Line2 – empty: “configuration #”
  - Line3 – empty

### **Setting Recall Parameters**

Recall#: Sets which user bin to recall.

Level: Displays the name of the selected user bin.

# 9 Operating Instructions

## ***Quick Start – Internal Single Shot Generator Operation***

Although the 9730 has a powerful set of feature extensions that allow the user to cater it to many unique test setups, the following steps may be followed to quickly generate a single shot internally generated pulse. Starting from the default settings, which can be recalled by recalling configuration 0, the following parameters need to be set:

### **Pulse Width, Delay**

Enter the Channel menus by pressing the appropriate [channel key](#). Enter the required pulse width and delay. Repeat for each output channel.

### **Amplitude**

Enter the channel menus as specified in the previous step. Press the channel menu an additional time to display the second parameter page. Enter the desired current amplitude. Repeat for each output channel.

### **Enable**

Enter the channel menus as specified in the previous step. Use the up arrow key to change the first line of the display to read 'Enabled'. Repeat for each output channel.

### **Interlock**

Make sure the Safety Interlock on the rear panel is shorted with either a setup specific safety connection or the 50 Ohm interlock bypass (shipped with the instrument accessories).

### **Wait for Charge**

When the Safety Interlock is properly shorted the instrument will charge up the capacitor banks for each channel (regardless of whether the channel is enabled or not). When the [channel 'CHARGE READY' LEDs](#) become illuminated, proceed to the next step.

### **ARM Key Switch**

Turn the [Arm Key Switch](#) to the ARM position. If the [system 'ARM' LED](#) or the desired [channel 'ARMED' LEDs](#) do not illuminate, the previous two steps need to be revisited.

### **Start**

Press the **RUN/STOP** key to generate a single pulse for each enabled channel.

## ***Quick Start – Single Shot External Trigger Operation***

To generate a single pulse for single external trigger event, based on the default configuration 0, the following parameters need to be set:

### **Trig**

Enter the trigger menu by pressing the **TRIG** key. Change mode to 'Enabled'.

### **Level**

Press the **NEXT** key to select the trigger threshold voltage parameter. Adjust to approximately 50% of the trigger signal amplitude.

### **Edge**

Press the **NEXT** key to select the Edge parameter. Set the instrument to trigger off the rising edge or falling edge as desired.

### **Filter**

Press the **TRIG** key to select the next page. Select the filter to be enabled or disabled. If enabled, press the **NEXT** key to select the filter width. Adjust the filter width to be shorter than the external trigger pulse width but longer than any "errant" pulses.

### **Source**

Press the **NEXT** key to select the trigger source. Select either front or rear input.

### **Pulse Width, Delay**

Enter the Channel menus by pressing the appropriate [channel key](#). Enter the required pulse width and delay. Repeat for each output channel.

### **Amplitude**

Enter the channel menus as specified in the previous step. Press the channel menu an additional time to display the second parameter page. Enter the desired current amplitude. Repeat for each output channel.

### **Enable**

Enter the channel menus as specified in the previous step. Use the up arrow key to change the first line of the display to read 'Enabled'. Repeat for each output channel.

### **Interlock**

Make sure the Safety Interlock on the rear panel is shorted with either a setup specific safety connection or the 50 Ohm interlock bypass (shipped with the instrument accessories).

### **Wait for Charge**

When the Safety Interlock is properly shorted the instrument will charge up the capacitor banks for each channel (regardless of whether the channel is enabled or not). When the [channel 'CHARGE READY' LEDs](#) become illuminated, proceed to the next step.

### **ARM Key Switch**

Turn the [Arm Key Switch](#) to the ARM position. If the [system 'ARM' LED](#) or the desired [channel 'ARMED' LEDs](#) do not illuminate, the previous two steps need to be revisited.

### **Start**

Press the **RUN/STOP** key to allow the unit to generate a single pulse for each enabled channel at the next external trigger event.

## ***Standard Operation Modes***

### **System Pulse Generation Overview**

Please refer to the [System Timer Functions](#) section for an overview of how the system generates system pulses. System modes are controlled via the [MODE menu](#).

### **Single Shot Mode (Trigger Disabled)**

The **RUN/STOP** button triggers a single pulse for each enabled channel. To generate channel pulses in single shot mode:

- In the system **MODE** menu: Set to 'Single Shot' mode.
- In the channel menu: Set desired channels to 'Enabled'.
- Verify the rear panel Safety Interlock.
- Turn Arm Switch to 'ARM' Position.
- Run Pre-Test if enabled and resolve any resulting error conditions.

Pressing the **RUN/STOP** key will now generate a single pulse for each enabled channel.

**NOTE: All operation modes require the [Interlock](#) to be in place and the [Arm Switch](#) to be in ARM position.**

### **Burst Mode (Trigger Disabled)**

The **RUN/STOP** button causes each channel to generate exactly the number of pulses specified by that channel's [burst count](#). The rate of pulse generation is

specified in the RATE menu. Pressing the **RUN/STOP** button while the burst is in process will stop the output. After the burst has been completed, pressing the **RUN/STOP** button will generate another burst. To generate a burst of pulses:

- In the system **MODE** menu: Set to 'Burst' mode.
- In the system **RATE** menu: Set the desired period.
- In the system **TRIG** menu:
  - Set trigger mode to 'Enabled'.
  - Set trigger level.
  - Set trigger edge.
- In the channel menu:
  - Set desired channels to 'Enabled'.
  - Set the desired burst count for each enabled channel.
- Verify the rear panel Safety Interlock.
- Turn Arm Switch to 'ARM' Position.
- Run Pre-Test if enabled and resolve any resulting error conditions.

Pressing the **RUN/STOP** key will now generate a burst of pulses for each enabled channel.

**NOTE: All operation modes require the [Interlock](#) to be in place and the [Arm Switch](#) to be in ARM position.**

### **External Input Overview**

The front and rear panel external inputs may be used to trigger the system and/or channel timers. Depending on the system mode, the result of a trigger input can be either a single channel pulse, or a burst of channel pulses. The external input has both level and filter options so that only the desired pulse type (amplitude and width) is able to trigger the unit.

- Trigger Level. This sets a threshold level that the input trigger must be higher than before it will become active. Typically, this level should be set to a 50% level of the input trigger amplitude. This level can be used to filter out any pulses that are not of sufficient amplitude. Care must be taken that the level is not set too low as this could cause triggering off of a bias or noise floor level.
- Filter Width. When enabled, the filter width can be adjusted so that the unit will not accept any trigger pulse widths that are less than the set filter width. This allows for filtering out of errant or "runt" pulses that may be caused by noisy environments.

### **Single Shot Mode (Trigger Enabled)**

The external trigger input triggers a single pulse for each enabled channel. To generate channel pulses in single shot mode with the trigger enabled:

- In the system **MODE** menu: Set to 'Single Shot' mode.
- In the system **TRIG** menu:
  - Set trigger mode to 'Enabled'.
  - Set trigger level.
  - Set trigger edge.
- In the channel menu: Set desired channels to 'Enabled'.
- Verify the rear panel Safety Interlock.
- Turn Arm Switch to 'ARM' Position.
- Run Pre-Test if enabled and resolve any resulting error conditions.

Pressing the **RUN/STOP** key will now allow a single pulse for each enabled channel at the next external trigger event.

**NOTE: All operation modes require the [Interlock](#) to be in place and the [Arm Switch](#) to be in ARM position.**

### **Burst Mode (Trigger Enabled)**

The **RUN/STOP** button causes each channel to generate exactly the number of pulses specified by that channels [burst count](#). The rate of pulse generation is determined by the rate of the external trigger pulses. Pressing the **RUN/STOP** button while the burst is in process will stop the output. After the burst has been completed, pressing the **RUN/STOP** button will arm the unit for the next set of external trigger pulses. To generate a burst of pulses:

- In the system **MODE** menu: Set to 'Burst' mode.
- In the system **RATE** menu: Set the desired period.
- In the channel menu:
  - Set desired channels to 'Enabled'.
  - Set the desired burst count for each enabled channel.
- Verify the rear panel Safety Interlock.

- Turn Arm Switch to 'ARM' Position.

Pressing the **RUN/STOP** key will now allow a burst of pulses for each enabled channel at the next external trigger events.

**NOTE: All operation modes require the [Interlock](#) to be in place and the [Arm Switch](#) to be in ARM position.**

## ***Special Testing Modes***

### **Pre Pulse Resistance Testing**

The 9730 allows the user to setup a pre pulse resistance test that, when enabled, must run and pass within the user specified range before allowing pulses to be generated for any enabled channel. To use pre pulse resistance testing:

- Setup the system mode, period and channel pulse parameters as described in the [Standard Operation Modes](#) section.
- In the Channel Test Menu:
  - Set PreTest to 'Enabled'
  - Set ResMax to the maximum "Go" resistance
  - Set ResMin to the minimum "Go" resistance
- Verify the rear panel Safety Interlock.
- Turn Arm Switch to 'ARM' Position.
- Press the **FUNC** key and then the **PRE** key ( '.' on the numeric keypad) to run the pre pulse resistance test.
- Refer to [Testing Mode Error Conditions](#) for more information on any resulting errors.

### **Post Pulse Resistance Testing**

The 9730 allows the user to setup a post pulse resistance test that, when enabled, may be run at anytime to verify the resistance of the connected load is greater than a user specified minimum. To use pre pulse resistance testing:

- Setup the system mode, period and channel pulse parameters as described in the [Standard Operation Modes](#) section.
- In the Channel Test Menu:
  - Set PostTest to 'Enabled'
  - Set ResMin to the minimum resistance expected for a "fired" device.

- Verify the rear panel Safety Interlock.
- Turn Arm Switch to 'ARM' Position.
- Press the **FUNC** key and then the **POST** key ( '.' on the numeric keypad) to run the post pulse resistance test.
- Refer to [Testing Mode Error Conditions](#) for more information on any resulting errors.

### **Testing Mode Error Conditions**

- **Error 1 - "Valid Pre-Test Required"** – This message is displayed when the **RUN/STOP** key has been pressed and one or more channels with pre pulse resistance testing have not yet passed testing.
  - Simultaneous flashing of the 'RESISTOR FAULT' and 'GROUND FAULT' LEDs indicate the test has not yet been run (or re-run since the last pulsing attempt).
  - Alternating flashing of the 'RESISTOR FAULT' and 'GROUND FAULT' LEDs indicate the test was performed but the resistance was determined to be outside the valid range.
- **Error 2 - "Resistance Out Of Range"** – This message is displayed when the pre pulse resistance testing has been run, and one or more channels were determined to have a resistance outside the valid range.
- **Error 3 - "Ground Fault"** – This message is displayed when the post pulse resistance testing has been run, and one or more channels were determined to have a resistance less than the set minimum.

# 10 Programming the 9730

## ***Personal Computer to Pulse Generator Communication***

The 9730 comes standard with a RS232 serial and USB interface. An Ethernet interface is available as an option. All menu settings can be set and retrieved over the computer interface using a simple command language. The command set is structured to be consistent with the Standard Commands for Programmable Instruments (SCPI). Although due to the special features optional in the 9730, some of the commands are not included in the specification. The syntax is the same for all interfaces.

## **RS232 Interface Overview**

The serial port is located on the back of the 9730 and uses a 9-pin D-type connector with the following pin-out (as viewed from the back of the unit):

- ❖ No Connection
- ❖ Tx – Transmit (to computer)
- ❖ Rx – Receive (from computer)
- ❖ DTR – Connected to pin 6
- ❖ Ground
- ❖ DSR – connected to pin 4
- ❖ RTS – Connected to pin 8
- ❖ CTS – Connected to pin 7
- ❖ No Connection

The serial port parameters should be set as follows:

- Baud Rate
  - 115200 (default)
  - 57600
  - 38400
  - 9600
  - 4800
- Data Bits
  - 8
- Parity
  - None
- Stop Bits
  - 1

\*The default baud rate for the RS232 is 115200

## **USB Interface Overview**

The USB interface is standard on the 9730. Before this type of communication can be used, the appropriate drivers must be installed on the personal computer. These drivers are included on the disc that was shipped with your unit. Please contact Quantum Composers or visit [www.quantumcomposers.com](http://www.quantumcomposers.com) for updated installation files and instructions.

USB communication is achieved by using a mapped (virtual) COM port on your computer. The driver installation executable will obtain an unused COM port number, install the USB drivers, and make that COM port number available for typical RS232 communication to the pulse generator. HyperTerminal or other common software may be used.

When communicating through the mapped COM port over USB, the baud rate for the communication port used by the USB chip must match the baud rate for the COM port of your computer. The USB baud rate is set at 38400.

USB communication notes:

- The correct drivers must be installed on your computer before communication can be accomplished via USB.
- The BAUD rate on your computer must be set to 38400 for successful communication.
- USB 1.0 specification is used. The USB cable can be removed without “unplugging” the device in the operating system environment.

## **Ethernet Interface Overview**

The Ethernet interface used in the 9730 is a “Digi Connect ME” module supplied by Digi Connectware, Inc. There are several ways to successfully communicate with the pulse generator over Ethernet. The two most popular methods are raw TCP/IP (such as Labview or programming with VISA libraries) and by mapping your computer’s COM port using the Digi Connectware’s “Realport Drivers”.

Whatever method of Ethernet communication is ultimately desired, the utilities supplied by Digi Connectware (included on the disc shipped with the Ethernet-optional pulse generator) will be critical to implementing the communications. Please install these utilities.

Ethernet communication notes:

- The Digi Connectware’s “Digi Device Discovery” can be used to determine what IP address was assigned by the local DHCP server (if any).
- “Digi Device Discovery” can also be used to open a web interface to the Ethernet module. Simply double-click on the IP address that is displayed in the Digi Device Discovery utility.
  - Username: “root”
  - Password: “dbps”
- If a mapped COM port is the desired communication method, the Digi Connectware’s “Realport Drivers” setup must be used to install the COM port on your computer. Please refer to the Digi Connectware documentation supplied on the disc, or call Quantum Composers technical support.

## ***Programming Command Types and Format***

The 9730 Pulse Generator uses two types of programming commands: IEEE 488.2 Common Commands and Standard Commands for Programmable Instruments (SCPI). The format is the same for all interfaces. HyperTerminal (in Windows) or any other generic terminal program may be used to interactively test the commands using the RS232 interface. The format of each type is described in the following paragraphs.

### **Line Termination**

The pulse generator uses text-style line terminations. When a command is sent to the unit the firmware is programmed to read characters from a communication port until it reads the line termination sequence.

The command string is parsed and executed after reading these characters. These characters are the “carriage return” and “linefeed”. They are ascii character set values 13 & 10 respectively (hex 0x0D and 0x0A). All command strings need to have these characters appended.

When the pulse generator responds to a command, whether it is a query or a parameter change, it also appends its return strings with these characters. Coded applications could use the behavior to know when to stop reading from the unit. However, if the “echo” parameter is enabled, there will be two sets of line terminators, one following the echoed command string, and the one following the pulse generator’s response.

Note: The pulse generator will echo commands on the DB9 serial port only.

The pulse generator responds to every communication string. If the communication string is a query, the unit responds with the queried response (or error code) followed by the line terminators. If the communication string is a parameter change, the response is “ok” (or error code) followed by the line terminators. For this reason, it is not recommended that multiple commands be stacked together into single strings as is common with some other types of instruments. It is recommended that the coded application send a single command in a string and follow immediately by reading the response from the unit. Repeat this sequence for multiple commands.

### **IEEE 488.2 Common Command Format**

The IEEE 488.2 Common Commands control and manage generic system functions such as reset, configuration storage and identification. Common commands always begin with the asterisk (\*) character and may include parameters. The parameters are separated from the command mnemonic by a space character. For example:

```
*RCL 1      <cr> <lf>
*IDN?      <cr> <lf>
```

### **SCPI Command Keywords**

SCPI commands control and set instrument specific functions such as setting the pulsewidth, delay and period. SCPI commands have a hierarchical structure composed of functional elements that include a header or keywords separated with a colon, data parameters and terminators. For example:

### **SCPI Keyword Separator**

A colon (:) must always separate one keyword from the next lower-level keyword. A space must be used to separate the keyword header from the first parameter. If more than one parameter is used, you must separate subsequent parameters with a comma.

## **SCPI Optional Keywords**

Optional keywords and/or parameters appear in square brackets ([]) in the command syntax. Note that the brackets are not part of the command and should not be sent to the pulse generator. When sending a second level keyword without the optional keyword, the pulse generator assumes that you intend to use the optional keyword and responds as if it had been sent.

## **SCPI Parameter Types**

The following parameter types are used:

- <numeric value>
  - Accepts all commonly used decimal representation of numbers including optional signs, decimal points and scientific notation: 123, 123e2, -123, -1.23e2, .123, 1.23e-2, 1.2300E-01.
- <Boolean value>
  - Represents a single binary condition that is either true or false. True is represented by a 1 or ON; false is represented by a 0 or OFF. Queries return 1 or 0.
- <identifier>
  - Selects from a finite number of predefined strings.

## **Legacy Command Support**

In addition to IEEE 488.2 and SCPI formatted commands, the 9730 Series also supports all legacy 971x commands for ease of software migration from the 971x instruments. Legacy commands begins with a '\$' symbol with each command keyword separated by a ':' (e.g. "\$T1:WID ?" will return the width for channel 1). For more information on legacy commands, please refer to the 971x series manual.

## **Error Codes**

The unit responds to all commands with either:

ok<cr><lf> or ?<n><cr><lf>      <cr> = carriage return, <lf> = line feed

Where "n" is one of the following error codes:

- 1      Incorrect prefix, i.e. no colon or \* to start command.
- 2      Missing command keyword.
- 3      Invalid command keyword.
- 4      Missing parameter.
- 5      Invalid parameter.
- 6      Query only, command needs a question mark.
- 7      Invalid query, command does not have a query form.
- 8      Command unavailable in current system state.

## ***Programming Examples***

### **Example 1:**

20 ms pulsewidth, 2.3 ms delay, internal trigger, single shot operation.

```
:PULSE0:MODE SING<cr><lf> sets system mode to single shot
:PULSE0:TRIG:MODE DIS<cr><lf> disables the external trigger
:PULSE1:WIDT 0.020<cr><lf> sets pulsewidth to 20 ms
:PULSE1:DELAY 0.0023<cr><lf> sets delay to 2.3 ms
:PULSE1:STATE ON<cr><lf> enables channel A
```

To start the pulses use either of the following commands:

```
:PULSE0:STATE ON<cr><lf> starts the pulses
:INST:STATE ON<cr><lf> alternate form to start pulses.
```

### **Example 2:**

20 ms pulsewidth, 100ms rate, 4 burst, internal trigger, burst mode operation.

```
:PULSE0:MODE BURST<cr><lf> sets system mode to burst
:PULSE0:RATE 0.1<cr><lf> sets the system rate to 100 ms
:PULSE0:TRIG:MODE DIS<cr><lf> disables the external trigger
:PULSE1:WIDT 0.020<cr><lf> sets pulsewidth to 20 ms
:PULSE1:STATE ON<cr><lf> enables channel A
```

To start the pulses use either of the following commands:

```
:PULSE0:STATE ON<cr><lf> starts the pulses
:INST:STATE ON<cr><lf> alternate form to start pulses.
```

## 9730 SCPI Command Summary

### Instrument Commands

| Keyword     | Parameter       | Comments   |
|-------------|-----------------|--|
| :INSTrument |                 | Subsystem  |
| :CATalog    |                 | Query only. Returns a comma-separated list of the identifier strings for all channels. A two channel instrument would return: T <sub>0</sub> , CHA, CHB.                                     |
| :FULL       |                 | Query only. Returns a comma-separated list of the identifier strings of all channels and their associated number. A two channel instrument would return: T <sub>0</sub> , 0, CHA, 1, CHB, 2. |
| :COMMands   |                 | Query only. Returns an indented list of all SCPI commands.   |
| :NSElect    | <numeric value> | Selects a channel using the channel's numeric value. All channel specific commands will refer to the selected channel.   |
| :SElect     | <identifier>    | Selects a channel using the channel's identifier string. All subsequent channel specific commands will refer to the selected channel.  |
| :STATe      | <boolean value> | Enables/Disables the selected channel output. If T <sub>0</sub> is selected all output is affected. Enabling T <sub>0</sub> is the same as pressing the RUN button.                          |
| :PRETest    | <boolean value> | Runs the resistance pre-test for all pre-test enabled channels.  |
| :POSTtest   | <boolean value> | Runs the resistance post-test for all pre-test enabled channels.   |

## System Pulse Commands

| Keyword             | Parameter                   | Comments   |
|---------------------|-----------------------------|--|
| :SPULSe or PULSe[0] |                             | Subsystem. Contains commands to control the output pulse generation. Commands without suffix refer to the currently selected logical instrument. See INSTRUMENT subsystem. |
| :STATe              | <boolean value>             | Enables / Disables the output for all channels. Command is the same as pressing the RUN/STOP button.   |
| :PERiod             | <numeric value>             | Sets the $T_0$ period.   |
| :MODE               | SINGle / BURSt              | Sets the $T_0$ mode.   |
| :FSYNc              | DIS / T0 / CHA / CHB / etc. | Sets the pulse source for the front panel sync output.   |
| :RSYNc              | DIS / T0 / CHA / CHB / etc. | Sets the pulse source for the rear panel sync output.  |
| :TRIGger            |                             | Subsystem. Contains the commands to define the Trigger function.   |
| :MODE               | <boolean value>             | Sets Trigger Mode. Disable or TRIG (enable).   |
| :TSOURCE            | FRONTpanel / REARpanel      | Switches the system trigger source between front or rear panel inputs.   |
| :EDGE               | FALLing / RISing            | Selects which edge (rising or falling) to use as the trigger signal.   |
| :LEVel              | <numeric value>             | Sets the Trigger Threshold. Value is in volts, with a range of .20 to 15 Volts.  |
| :FENable            | <boolean value>             | Enables/Disables the trigger pulse width filter.   |
| :FILTer             | <numeric value>             | Sets the trigger minimum pulse width value.  |
| :COUNT              |                             | Subsystem. Contains commands to manipulate the system shot counter ( $T_0$ pulses)   |
| :STATe              | <boolean value>             | Enables/Disables the system shot counter.  |
| :CLear              | 0                           | Clears the system shot counter.  |
| :COUNT              |                             | Query Only. Returns the value of the system shot counter.  |

## Channel Commands

| Keyword     | Parameter       | Comments  |
|-------------|-----------------|---|
| :PULSe<n>   |                 | Subsystem. Contains commands to control the output pulse generation. Valid suffix values depends on the number of channels (ChA = 1, ChB = 2, etc). Command without suffix refers to the currently selected logical instrument. See INSTRument subsystem. |
| :STATe      | <boolean value> | Enables/Disables the output pulse for selected channel.   |
| :WIDTh      | <numeric value> | Sets the width or duration of the output pulse.   |
| :DELay      | <numeric value> | Sets the time from the start of the $T_0$ period to the first edge of the pulse.  |
| :SYNC       |                 | Selects the syncsource.   |
| :BCOunter   | <numeric value> | Burst Counter. Sets the number of pulses to generate when channel is in the BURST mode.   |
| :AMPLitude  | <numeric value> | Sets adjustable output level.   |
| :PRETest    |                 | Subsystem. Contains commands for control and monitoring of the channel pre-test parameters.   |
| :MODE       | <boolean value> | Enables/Disable the channel pre-test.   |
| :MAXres     | <numeric value> | Sets the maximum valid resistance for pre-test.   |
| :MINres     | <numeric value> | Sets the minimum valid resistance for pre-test.   |
| :RESistance |                 | Query Only. Returns the last measured resistance from the pre-test.   |
| :POSTtest   |                 | Subsystem. Contains commands for control and monitoring of the channel post-test parameters.  |
| :MODE       | <boolean value> | Enables/Disable the channel post-test.  |
| :MINres     | <numeric value> | Sets the minimum valid resistance for post-test   |
| :RESistance |                 | Query Only. Returns the last measured resistance from the post-test.  |
| :ERRor      |                 | Query Only. Returns errors resulting from running the pre or post tests on this channel. Refer to <a href="#">Testing Mode Error Conditions</a> for more information.   |

## Display Commands

| Keyword     | Parameter       | Comments  |
|-------------|-----------------|---|
| :DISPlay    |                 | Subsystem. Contains commands to control the display.  |
| :MODE       | <boolean value> | Enables/Disables automatic display update. When true, front panel display is updated with serial command parameter changes. Setting to false decreases response time. |
| :UPDate     |                 | Query only. Forces update of display. Use when mode is false.   |
| :BRIGHtness | <numeric value> | Controls intensity of display. Range is 0 to 4, where 0 is off and 4 is full intensity.   |

## System Commands

| Keyword      | Parameter  | Comments  |
|--------------|--|---|
| :SYSTEM      |  | Subsystem   |
| :STATe       |  | Query only. Returns "1" if the system is armed and/or generating pulses or "0" if the system has been disarmed. |
| :BEEPer      |  | Subsystem. Controls the audible beeper.   |
| :STATe       | <boolean value>                                    | Enables/disables the beeper.  |
| :VOLume      | <numeric value>                                    | Sets the volume of the beeper. Range is 0 to 100, where 0 is off and 100 is maximum volume                      |
| :COMMunicate |  | Subsystem. Controls the system communication parameters   |
| :SERial      |  | Subsystem. Controls the serial parameters.  |
| :BAUD        | 4800 / 9600 /<br>19200 / 38400 /<br>57600 / 115200 | Sets the baud rate for both receiving and transmitting using the RS232 port.                                    |
| :USB         | 4800 / 9600 /<br>19200 / 38400 /<br>57600 / 115200 | Sets the baud rate for communication when using virtual com ports for USB.                                      |
| :ECHO        | <boolean value>                                    | Enables/Disables transmission of characters received on the RS232 port.   |
| :KLOCK       | <boolean value>                                    | Locks the keypad.   |
| :VERSion     |  | Query only. Returns SCPI version number in the form: YYYY.V ex. 1999.0  |
| :INFOrmation |  | Query Only. Returns model and version information for the instrument.   |
| :NSID        |  | Query Only. Returns the instrument ID for use when upgrading firmware.  |

## IEEE 488.2 Common Commands

| Mnemonic | Command Name         | Parameters      | Comments  |
|----------|----------------------|-----------------|---|
| *IDN?    | Identification Query |                 | Queries the Pulse Generator Identification. The ID will be in the following format:<br><b>model#,serial#,version#</b>   |
| *LBL     | Label Command/Query  | <string value>  | Query Form returns the label of the last saved or recalled configuration. Command Form sets the label string for the next "*sav" command. String must be in double quotes, 14 characters max. |
| *RCL     | Recall Command       | <numeric value> | Restores the state of the Pulse Generator from a copy stored in local nonvolatile memory (0 through 12 are valid memory bins).  |
| *RST     | Reset Command        |                 | Resets the Pulse Generator to the default state.  |
| *SAV     | Save Command         | <numeric value> | Stores the current state of the Pulse Generator in local nonvolatile memory (1 through 12 are valid memory bins).   |
| *SER?    | Serial # Query       |                 | Returns the serial # of the Instrument.   |
| *TRG     | Trigger Command      |                 | Generates a software trigger pulse. Operation is the same as receiving an external trigger pulse.   |

## Appendix A - Specifications

|                         |   |  |
|-------------------------|---|--|
| I/O Configuration       |   |  |
|                         | Output Modules                                | 9732 – 2 Output Channels   |
|                         |   | 9734 – 4 Output Channels   |
|                         | Input Module                                  | Front and Rear Trigger   |
| Internal Rate Generator |   |  |
|                         | Rate  | 0.01Hz to 100KHz   |
|                         | Resolution                                    | 100ns  |
|                         | Accuracy                                      | 20ns   |
|                         | Jitter  | 10ns RMS   |
|                         | Burst Mode                                    | 1 to 250 pulses  |
|                         | Output Modes                                  | Single Pulse, Burst  |
|                         | Control Modes                                 | Internal Rate Generator,<br>External Trigger                       |
|                         |   |  |
| External Trigger Inputs |   |  |
|                         | Function                                      | Generate individual pulses<br>(single shot or burst)               |
|                         | Front or Rear                                 | Selectable between front or<br>rear panel inputs                   |
|                         | Rate  | DC to 1/(330ns + longest<br>active pulse)                          |
|                         | Insertion Delay                               | 330ns  |
|                         | Jitter  | 10ns   |
|                         | Impedance                                     | 1K   |
|                         | Slope   | Rising or Falling  |
|                         | Trigger Filter                                | Filters out unwanted<br>“glitch” or “runt” pulses                  |
|                         | Range   | 0.02us to 1ms  |
|                         | Resolution                                    | 0.02us   |
|                         | Trigger Level                                 | 2-15V  |
|                         | Level Threshold Resolution                    | 100mV  |
|                         |   |  |
| Outputs                 |   |  |
|                         | Amplitude                                     | 0.10 – 6A  |
|                         | Resolution                                    | 1mA  |
|                         | Accuracy                                      | 2mA Typical  |
|                         | Voltage Level                                 | >20V   |
|                         | Slew Rates:                                   |  |
|                         | Rising Edge – Inductive<br>(Varies with load) | 2A/us @ 6A<br>1A/us @ 3A<br>0.30A/us @ 1A<br>(1 ohm and 50' cable) |

|                               |  |   |
|-------------------------------|--|---|
|                               | Falling Edge – Inductive<br>(Varies with load) | -1.60A/us @ 6A<br>-0.90A/us @ 3A<br>-0.30A/us @ 1A<br>(1 ohm and 50' cable) |
|                               | Rising Edge – Resistive<br>(Varies with load)  | 6.3A/us @ 6A<br>9.5A/us @ 3A<br>2.2A/us @ 1A<br>(1 ohm & 2" cable)          |
|                               | Falling Edge – Resistive<br>(Varies with load) | -5.2A/us @ 6A<br>-4.0A/us @ 3A<br>-1.3A/us @ 1A<br>(1 ohm & 2" cable)       |
|                               |  |   |
| <b>Rise Times</b>             |  |   |
|                               | Rising Edge – Inductive<br>(Varies with load)  | 4us (1 ohm, 50' cable, 6A)  |
|                               | Rising Edge – Resistive<br>(Varies with load)  | 550ns (1 ohm, 2" cable, 6A)   |
|                               |  |   |
|                               | Pulse Width Range                              | 5us – 100s*   |
|                               | Error  | +/-0.1%   |
|                               | Resolution                                     | 100ns   |
|                               |  |   |
|                               | Delay Range                                    | 0-1s  |
|                               | Error  | +/-0.1%   |
|                               | Resolution                                     | 100ns   |
|                               |  |   |
| <b>Monitor Outputs</b>        |  |   |
|                               | Voltage Monitor (Isolated)                     | 1V/V  |
|                               | Current Monitor (Isolated)                     | 1V/A  |
|                               | Error  | <4%   |
|                               | Bandwidth                                      | 150KHz  |
|                               |  |   |
| <b>Resistance Measurement</b> |  |   |
|                               | Range  | 0.1 to 150 Ohms   |
|                               | Resolution                                     | .01 Ohms  |
|                               | Error .5 to 15 Ohms                            | <4%   |
|                               | Error 16 to 150 Ohms                           | <10%  |
|                               | Measurement Current                            | 100mA Max.  |
|                               |  |   |
| <b>Sync Outputs</b>           |  |   |
|                               | Front and Rear                                 | T0, Channels A through D  |
|                               |  |   |
| <b>Safety</b>                 |  |   |
|                               | Remote Interlock                               | Shorting interlock  |

|   |                         |   |
|---|-------------------------|---|
|   | Arming Key switch       | Removable keyswitch                             |
|   |                         |   |
| Communications  |                         |   |
|   | RS232                   | 115200, 57600, 38400,<br>19200, 9600, 4800 baud |
|   | USB                     | Serial Bridge                                   |
|   | Ethernet                |   |
|   |                         |   |
| Size  | 19" 2U x 10" Rack Mount |   |
|   |                         |   |
| Electrical  | 100/240V, 50-60Hz       |   |
|   |                         |   |
| <p>* Actual output time is governed by the output current (I), capacitor bank voltage (Vcap), the capacitance (C), the measurement resistance (Rm), and the load resistance (RL). The governing equation is <math>T_{on} = V_{cap} * (C/I) - (R_m + R_L) * C</math></p> |                         |   |

# Appendix B - Safety Symbols

## ***Safety Marking Symbols***

Technical specifications including electrical ratings and weight are included within the manual. See the Table of Contents to locate the specifications and other product information. The following classifications are standard across all QC products:

- Indoor use only
- Ordinary Protection: This product is NOT protected against the harmful ingress of moisture
- Class 1 Equipment (grounded type)
- Main supply voltage fluctuations are not to exceed 10% of the nominal supply voltage
- Pollution Degree 2
- Installation (overvoltage) Category II for transient over-voltages
- Maximum Relative Humidity: <80% RH, non-condensing
- Operating temperature range of 0 to 40 degrees Celsius
- Storage of transportation temperature of -40 to 70 degrees Celsius
- Maximum altitude 3000m (9843 ft.)
- This equipment is suitable for continuous operation.

This section provides a description of the safety marking symbols that appear on the instrument. These symbols provide information about potentially dangerous situations which can result in death, injury, or damage to the instrument and other components.